

HOW TO RESET YOUR COMBINATION LOCK



The opening combination is preset at the factory at 0-0-0.

Step 1 Turn the dials to the opening combination.

Step 2 Press down the Reset Button with a pen (or other tools) all the way until you hear the "Click" sound (fig. 1)

Step 3 Turn dials to set your own combination.

Step 4 Push the Buttons to pop out the Reset Button to original position (fig. 2)



The lock will now open to your personal combination.

Record your combination in a safe and accessible place for future reference.



NOTE:

The Transportation Security Administration (TSA) screeners and airline check-in staff at airports are trained to recognize the Travel Sentry™ logo.

They understand that baggage with locks displaying this mark are permitted to remain locked.

TSA screeners have access to special codes that allow them to open these locks in the event that the baggage must be opened for inspection.

With Travel Sentry™ Certified locks the TSA can screen checked baggage faster, without having to break open locks.